XNET IP Installation Wizard User's Manual

Ver. 1.0 (090826)

Table of Contents

1. XI	NEI IP Installation Wizard	4
	1.1 System Requirement	
	1.2 XNET IP Installation Wizard	
	1.2.1 VS/NC Setup	
	1.2.2 Router Setup	

Read this First

This product is made by advanced technology and passed reliability and compatibility test. Product quality can be guaranteed.

This is an operation guide for XNET-Series user.

If you are first user of XNET-Series, even though you are experienced with similar products like this, we recommend you to read this manual carefully and follow the instructions inside before using this product.

CAUTION

- The copyright of this manual belongs to original manufacturer.
- We do not guarantee, if your system is damaged by your mis-using disapproval components or mis-operation.
- If you have any problems or questions with our product, please contact the dealer you bought from or original manufacturer.
- If you need to open the system for modification or repairing, it is recommended that you have to request an engineer's assistance by contacting the dealer you bought it from or original manufacturer.
- This product has certification for domestic and industrial use. Also, it has taken CE for Europe, FCC for the U.S.

1. XNEI IP Installation Wizard

In order to connect to XNET Video Server / Network Camera from Client Program, IP address should be assigned to Video Server / Network Camera.

From now, abbreviation will be used.

VS: Abbreviation for Video Server

NC: Abbreviation for Network Camera.

1.1 System Requirement

Hardware Recommended:

CPU: 300 MHz or Faster RAM: 128 MB or More.

Operating System:

Windows XP and Windows VISTA

1.2 XNET IP Installation Wizard

IP Installation Wizard guides you to assign IP address to VS/NC and to setup router's DMZ or Port-Forwarding for VS/NC in order to connect to XNET VS/NC from Client Program

After you run the Installation Wizard program, you will see the start page like below.



Setup: Start to setup VS/NC

User guide: Open the program user manual document.

Exit: Finish the VS/NC Installation Wizard program.


End User License Agreement

Please read the End User License Agreement carefully. If you agree with the agreement, please check the checkbox and click Next button. Otherwise, click Exit button o finish Installation Wizard.



Select VS/NC Setup or Router Setup.


Please check the type of setup you want to process, and click Next button.



Network Camera Setup: Assigning IP address to VS/NC Router Setup: VS/NC's DMZ or Port-Forwarding Setup


1.2.1 VS/NC Setup

VS/NC Setup




Please click Next button after you connect VS/NC to your network like the above picture.

***** VS/NC Device Search



After the Wizard search VS/NC from your network, you can setup them.



If you select a VS/NC on the list, you can check its network information.

Search: Searching for VS/NC in your network.


Manual Setup: If VS/NC is not appeared on the list, you can setup manually.

Setup: Setup VS/NC that is on the list.

Finish: Exit VS/NC setup page.

Manual Setup

You can setup VS/NC manually by MAC address; however, you can only assign VS/NC's IP address.




Please input VS/NC MAC address, and then please select a network adapter. After that, please input IP address that you want to assign at VS/NC.


Setup

Select a VS/NC from the list, and then click Setup button.

Select your Network adapter, and input IP address, subnet mask, Gateway, Http port, and Rtsp port.



If you use router in your network, you can do port forwarding by clicking Router Setup button.



Here is the supportable router list

Anygate: RG-3500A


IPTime : G104

Linksys : WRT54GC Netgear : KWGR614 Belkin : 4.03.03 These routers are test completed models, however, it may does not work depending on the firmware version. Input router's ID and password, then click Save button.

1.2.2 Router Setup


Router Setup

Router installation Wizard guides you to setup router's DMZ or Port-Forwarding for VS/NC in order to connect to XNET VS/NC from Client Program



Router Selection

Select your router's manufacture and model.



Here is the supportable router list

Anygate : RG-3500A
IPTime : G104
Linksys : WRT54GC
Netgear : KWGR614

Belkin : 4.03.03

These routers are test completed models, however, it may does not work depending on the firmware version. Input router's ID and password, then click Save button.

If you do not find your router from the list, please click Manual Setup button to setup DMZ or port forwarding via router web page setup.


Please click Next button to continue the process.

Router Connection Setup

Please input router ID, Password, and Http port, then click Next button.




VS/NC Selection



Select VS/NC to setup DMZ or port forwarding, then click Next button.

VS/NC Connection Setup


You can assign Http port, Camera ID and Password




Please click Next button after you input Http port, Camera ID and Password

Port Setup

Please input Http port and Rtsp Port for DMZ or port forwarding, then select DMZ or port forwarding. Please click Next button to finish router setup.



* Warning. If router already has DMZ or port forwarding setup values, newly inputted DMZ or port forwarding values will replace it.



Installation Complete

Router setup is completed.



Please click Finish button to go back to first page.